



Rapid-Vance 120 Roll Film Holder Guidebook

graflex




The Rapid-Vance 120 roll film holder can be used with Graflok® and Graphic® Backs.

To use the 120 roll film holder with a Graflok back, remove the focusing panel frame by simultaneously depressing the knurled finger pads and sliding the panet to the right. Fit the 120 roll film holder to the back of the camera and lock in place with the upper and lower slide locks.

With a Graphic back, a Spring Kit is required. Attach the 120 roll film holder in accordance with the instructions ac-

companying the kit.

Rapid-Vance 120 Roll Film Holder



Follow these 6 easy steps in loading the

RH/8—8 exposures, 2½ x 3½6 RH/10—10 exposures, 2½ x 2¾ RH/12—12 exposures, 2½ x 2½

1 Removing the carriage


Place the holder face down with dark slide to the right. Squeeze the release latches together and lift to open the cover, (Fig. 1.) Remove the carriage. A color dot is located on the frame next to the dark slide. This color dot should match the color of the advance lever on the film carriage—your cue to instant matching of carriage and frame, should you have more than one size roll holder.

2 Inserting the loaded spool

Load the full spool into the left hand compartment with the paper set — black side facing outward — to unwind counterclockwise. To insert spool, tip the edge of the spool into the cavity in the lower side of the roll holder carriage. Press it downward as far as possible . . . until the spool snaps into position (Fig. 2.)







3 Attaching Film to take-up spool

Hold the release lever to the left. Actuate the advance lever until the last number (8, 10, or 12) on the exposure counter passes the white line and the counter no longer turns. Unwind enough of the protective paper covering the film to pass around the front of the carriage into the take-up spool on the right (Fig. 3.) Thread the tab end of the paper into the wider slot of the take-up spool and actuate the advance lever approximately 1/2 stroke to make a complete turn of the spool, See that the paper is winding evenly between spool flanges. Continue to actuate the lever until the marker on the backing of the film is opposite the arrow on the inside of film carriage (Fig. 4.) Turn the exposure counter in the direction of the arrow - toward "S" - until it clicks into place and cannot be turned further.


4 Returning carriage to holder

Insert the carriage into the holder and close cover. For fullest operating convenience, the 120 roll film holder carriage may be positioned in the holder with the advance lever at the top or the bottom of the holder for either right or left hand operation (Fig. 5.)

5 Setting first exposure

Actuate the advance lever, and the paper leader on the film winds onto the take-up spool. When the No. 1 exposure position is reached, the advance lever will lock and the exposure counter will be indexed to 1, indicating the film is in position for first exposure.

In this position the end of the film strip is bent around the idler in a direction opposite its normal curl. This may introduce strain on the adhesive strip which holds the film to the paper backing and, under unfavorable humid conditions, the adhesive strip may loosen. So, do not advance the film to first exposure position until the first exposure can be made and the film then wound to the No. 2 mark.





6 Advancing film

The advance lever locks after each film advancement. To bring the film into position for next picture after an exposure has been made, move the release lever to the left and release. Advance the film with a full stroke of the advance lever. Follow this sequence for all exposures.

After the last exposure, move the release lever to the left. This leaves the advance lever free and permits the film to be wound completely onto the take-up spool.

Remove the full spool. Fold the paper trailer. Wrap it around the spool and seal it. Switch the empty supply spool to the take-up chamber. The carriage is ready for reloading.

Maintenance

This holder has been carefully designed to provide positive film flatness and film transport. Proper care will keep it operating "like new" for many years.


Before loading each roll of film, carefully remove all dust and dirt, especially from the film flatteners and carriage. Check to make sure the film flattener rollers are turning freely—a sticky roller may cause film scratches.

Every six months or after shooting 50 rolls of film, whichever occurs first, lubricate the sleeves (A) at each end of both film flattener rollers (see inset). Use only Molykote Type Z, Graffex part no. 39484P2. Make a mixture of Molykote and alcohol and apply one drop to each sleeve. Turn each roller, working the Jubricant deep into the sleeves.

When the alcohol carrier has evaporated, carefully wipe any excess Molykote from the exposed surfaces.

DO NOT USE OIL AS A LUBRICANT.

Check the guide plates (B). Both feet should be against the guide plate as shown (see inset). Make sure the guide plate screws and the retaining screws on the advance lever are tight.



Yer.

120 film holder replacement carriages. For 2V₄ x 3V₄ cameras, identified by colors.

Holder	Advance Le
RH/8	Red
RH/10	Blue
RH/12	Green

Replacement	Dark
Slides:	

21. No.	Color
432	Clear
432R	Red
432B	Blue
432G	Green
432Y	Yellow

YOUR GRAFLEX WARRANTY:

To the initial retail purchaser of Graflex merchandise:

Skilled craftsmen have produced the Graflex merchandise you have purchased. They have built into it a level of quality and performance which will insure your enjoyment of its use.

Graflex merchandise is warranted by Graflex and the Graflex Dealer from whom you purchased the same, to be free from faulty materials and workmanship, except as hereinafter set forth. If any time during your first year of ownership, (90 days in the case of any electronic components and parts, including without limitation, tubes and projection lamps), any servicing is necessitated by faulty material or workmanship, it will be provided (or the equipment replaced at our option) without charge except for transportation charges by your nearest Graflex Service facility. Returns for servicing should be made through your Graflex Dealer; or if this is not convenient, the merchandise should be carefully packed in a stiff container with adequate packing (not excelsion). Attach name and address and any specific instructions to the package, which should be adequately secured and fully insured.

THIS WARRANTY IS NOT APPLICABLE

- A. To Graflex merchandise which in our judgment has been damaged, abused, or requires replacement of parts due to wear and tear from use, or for any reason other than faulty materials and workmanship. Such merchandise will be serviced at factory-established rates.
- B. To Graflex merchandise which has been tampered with or serviced by persons other than Graflex approved personnel.
- C. If adaptations or accessories of other than Graffex recommendations have been made or attached.
- D. Where the Graflex merchandise bears serial numbers, if it has not been registered with Graflex by means of the attached registration card or appropriate substitute within 60 days from date of purchase.

No liability is assumed for film which is damaged or is unsatisfactory for any reason (due to equipment malfunction

or otherwise), nor is Graflex, Inc., obligated to replace such film.

EXCEPT AS EXPRESSLY SET FORTH HEREIN NO OTHER WARRANTIES ARE MADE BY GRAFLEX OR YOUR GRAFLEX DEALER WITH RESPECT TO GRAFLEX MERCHANDISE, INCLUDING, WITHOUT LIMITATION, WARRANTIES AS TO FITNESS FOR A PARTICULAR PURPOSE AND OF MERCHANTABILITY. No liability is assumed for expenses or damages resulting from interruptions in operation of equipment, nor for incidental or consequential damages of any nature.

In order that we may be able to pursue our continuing program of product improvement, Graffex reserves the right to make changes in design, or add improvements to any product without incurring any obligation to include such

revisions in equipment previously produced.

The warranties hereinbefore expressly set forth are made only to the original retail purchaser. Graflex's liability under the within warranty is limited to repair or replacement as hereinbefore provided.

SERVICE FACILITIES:

Graflex Approved Service Stations are conveniently located in all major cities. Contact your Graflex Dealer or write to the Manager, Graflex Service Sales, for the address of the Graflex Approved Service Station nearest you.

Record below such serial numbers as your equipment bears for your insurance file and future reference.

MASK SELECTION CHART

-for various film sizes (not camera size)-

The same of the sa					Annual Printers and Publishers and P	
MASK CATALOG NUMBER	2V4 x 2V4 PICTURE SIZE	21/4 x 24/4 PICTURE SIZE	21/4 x 31/4 PICTURE SIZE	3¼ x 4¼ PICTURE SIZE	4 x 5 PICTURE SIZE	
	FOCAL LENGTH OF LENSES IN MILLIMETERS					
9105-4 9105-3 9105-2 9105-9 9105-10 9105-11 9105-7 9105-5 9105-5 9105-12 9105-14 9105-14 9105-17 9105-17 9105-20 3060 W.A. Adapter	100 - 114 243 - 302 116 - 127 129 - 152 154 - 191 78 - 90	70 - 84 86 - 90 92 - 101 103 - 125 127 - 138 140 - 162 164 - 191 192 - 227 229 - 267 268 - 305	78 - 82 83 - 98 100 - 114 116 - 127 129 - 152 154 - 191 192 - 197 198 - 241 243 - 302 303 - 330	114 - 121 122 - 133 135 - 152 154 - 178 179 - 203 205 - 216 217 - 305 307 - 352 354 - 406 408 - 508	127 - 149 150 - 162 164 - 168 170 - 216 217 - 241 243 - 267 268 - 343 344 - 381 383 - 429 431 - 508	

Serve Million 3750 Montpe Avenue Rochuster, New York 14603

Western Region: 800 North Cole Avenue Hallywood, Carlfornia 90038

Midwest Region 5515 Million Parkway Resembet, Illnes 50018

Eastern Region: 411 Serie Drive Paramus, New Jersey 07652

Graffex of Canada Limited 47 Simcoe Street Tollinto I. Ontario, Canada GRAFLEX, Inc... Rochester, New York 14603, U.S.A. Subsidiary of General Precision

Equipment Corporation

